

PHOTO



DIMMER

LW - SERIEESC - SS

DESCRIPTION


LIGHTWILD'S SCENE SELECTOR IS A DIGITAL LIGHTING CONTROLLER THAT INSTALLS INTO A SINGLE GANG WALL BOX (SUPPLIED BY OTHERS) AND PROVIDES DIRECT WIRING CONNECTIONS TO A LIGHTWILD SERIES C OR SERIES D CONTROL UNIT.

STANDARD SHOWS* PROVIDED ON THE SCENE SELECTOR INCLUDE:

- **BUTTON #1:** SLOW COLOR CHANGES THROUGH ALL COLORS
- **BUTTON #2:** OCEAN BLUES AND GREENS
- **BUTTON #3:** SUNSET RED, ORANGE, AND YELLOW
- **BUTTON #4:** HOLIDAY RED, WHITE, AND BLUE
- **BUTTON #5:** STATIC COLOR RED
- **BUTTON #6:** STATIC COLOR GREEN
- **BUTTON #7:** STATIC COLOR BLUE
- **BUTTON #8:** STATIC COLOR WHITE

* INTENSITY LEVELS (DIMMING) CAN BE ADJUSTED UP AND DOWN ON ALL EIGHT SHOWS

WIRE CONNECTIONS



FEATURES

- **POWER INPUT:** 24 VDC
- **POWER OUTPUT:** NONE. DATA SIGNALS ARE OUTPUT ONLY.
- **ENVIRONMENT:** DRY LOCATION
- **TEMPERATURE RANGE:** -10 TO 150 F (-25 TO 65 C)
- **HOUSING:** INSTALLS INTO A SINGLE GANG WALL BOX (SUPPLIED BY OTHERS)
- **CONNECTORS:** ONE CONNECTOR FOR CAT5 CABLE. ONE 2-PIN CONNECTOR FOR 24VDC POWER CABLE.
- **DATA INPUT/OUTPUT:** CAT5 CABLE FROM LIGHTWILD DMX DIRECTOR

